



- = No traces on any layers. These edges will be machined and joined with adjacent FTBs and adhered to Al plate.
- = No traces or silk on top or bottom layers. These sections will be bolted to Al plate.